



LED CORNER LIGHTS M28-3XXXX

To keep texting drivers from hitting your parked car at night, Uncle Sam requires road-going vehicles to have side markers that are retroreflective and of specific color and location. To ensure our customers are in full compliance we are including some colored retroreflective stickers to go along with the LED side markers to maintain legality. To install them:

1. Determine how you would like to orient the sticker on the bumper cover. It should be as close to the LED corner light as possible and at least 15" above the ground. The amber stickers are for the front, the red stickers are for the rear.
2. Use rubbing alcohol or other paint-safe adhesive prep agent to clean the desired sticker placement area.
3. Apply the stickers to the locations as laid out in step one and you're done!

If you have any questions during installation or suggestions for improvement to the product or the instructions - please don't hesitate to call or email.